

ROOF ASSEMBLY

Roof Caps
#14 x 1 1/4" pan head screws

On a flat surface position boards as shown. Keep boards square while attaching roof cap to boards with #14 x 1 1/4" pan head screws.

Repeat for second roof assembly.

