

SAND BOX SEAT

1. Position sand box seat as shown and mark holes.
2. Drill $\frac{1}{8}$ " holes 1" deep into the board.
3. Attach with #14 x $1\frac{1}{4}$ " pan head screws

