

SplashAction

Water Cannon

Fill Your Water Slide or Play Firefighter

PS 7834



MADE IN
U.S.A.




Fig. 1

Tools Required:

Drill, 1/8" Drill Bit,
Phillips Screwdriver




Fig. 2

Mounting Instructions:

1. Determine desired location for pivot.
2. Drill a 1/8" dia. hole 1" deep.
3. Fasten pivot with #8 x 2 1/2" screw provided. **(Fig. 1)**
4. Snap *Water Cannon* onto pivot.
5. Attach hose provided to the end of *Water Cannon*.
6. Attach water regulator to the end of hose. **(Fig. 1)**
7. Secure hose to wood structure with clips and #8 x 1 1/4" screws provided. Make sure topmost clip is 12" below bottom of water cannon pivot and the length of hose from the cannon to this clip is 20". This ensures no entrapment or strangulation hazard will exist where hose attaches to the play station. **(Fig. 2)**
8. Attach your garden hose to water regulator.

Adult supervision is recommended for children of all ages.

For use by children ages 2 to 10.
Specifications subject to change without notice.

