



Wood

4' x 10' Frame Kit

Assembly Instructions



We're Here To Help!


Call Toll Free **1-888-752-9782**
Customer Service: Monday - Friday 8:00 a.m. to 5:00 p.m. C.S.T.

PS 1005


TABLE OF CONTENTS-COMMERCIAL GRADE DOCK KIT

Dock Layout and Frame Assembly (Floating Only)	4
Attaching Pipe Sleeves	5
Attaching Hinges	6
Attaching Floats	7
Dock Layout and Frame Assembly (Roll-In or Stationary)	8
Attaching Pipe Sleeves	9
Attaching Clips	10
How To Adjust Dock Height	12
Wood Top Assembly	13
Resin Dock Top Assembly	14
Attaching Accessories	15

COMMERCIAL GRADE DOCK KIT CONTENTS - PS 1005




(4) Outside Corner Brackets




(4) Inside Corner Brackets



(4) Corner Gussets




(4) Joist Corner Brackets




(8) Back Plates


COMMERCIAL GRADE DOCK KIT HARDWARE CONTENTS




(52) 3/8" x 3" Carriage Bolts



(52) 3/8" Lock Washers



(52) 3/8" Washers



(52) 3/8" Nuts

BILL OF MATERIALS

Stationary



Dock Top:

*(11) 5/4" x 6" x 8' Decking

Support Components:

- (2) Foot Plates PS 1023
- (1) Pipe Safety Caps PS 1193
- (4) Connector Clips PS 1021
- (2) Dock Pipes (1 5/8" or 1 7/8")
- (2) CG Pipe Sleeve PS 1080

Lumber:

- (5) 2" x 6" x 10'
- (2) 2" x 6" x 8'
- (229) #8 x 2 1/2" Deck Screws

Roll-In



Dock Top:

*(11) 5/4" x 6" x 8' Decking

Support Components:

- (1) Dock Wheel Axle Kit PS 1198
- (2) Wheels PS 1334
- (1) Pipe Safety Caps PS 1193
- (4) Connector Clips PS 1021
- (3) Dock Pipes (1 5/8" or 1 7/8")
- (2) CG Pipe Sleeve PS 1080

Lumber:

- (5) 2" x 6" x 10'
- (2) 2" x 6" x 8'
- (229) #8 x 2 1/2" Deck Screws

Floating



Dock Top:

*(11) 5/4" x 6" x 8' Decking

Support Components:

- (3) Dock Floats PS 1155
- (1) CG Pipe Sleeve PS 1080
- (1) Auger PS 1100
- (8) Back Plates PS 1017
- (4) Joist Corner Brackets PS 1015
- (1) Frame Hardware PS 1135
- (1) Float Hardware PS 1145
- (1) Pipe Safety Caps PS 1193
- (2) Hinge Kits PS 1070
- (1) Dock Pipes (1 5/8" or 1 7/8")

Lumber:

- (5) 2" x 6" x 10'
- (2) 2" x 6" x 8'
- (229) #8 x 2 1/2" Deck Screws

TOOLS REQUIRED

- Safety Glasses
- Measuring Tape
- Pencil
- Hammer
- Saw
- "C" Clamp
- Drill
- 1/8", 1/4" and 3/8" Drill Bits
- Carpenter's Square
- 3/8", 9/16" Socket and Ratchet

NOTE: *Resin Dock Top PS 1320 can be substituted for (11) 5/4" x 6" x 8' Decking

CUTTING GUIDE

2" x 6" x 10' – five (5) boards required

(5) boards	117"
------------	------

2" x 6" x 8' – two (2) boards required

(2) boards	48"	48"
------------	-----	-----

5/4" x 6" x 8' – eleven (11) boards required when attaching a Wood Top


(10) boards	48"	48"
-------------	-----	-----

(1) board	48"	
-----------	-----	--

READ ALL INSTRUCTIONS THOROUGHLY BEFORE YOU BEGIN CONSTRUCTION. FLOATING DOCK PROJECT STARTS HERE.



DOCK LAYOUT EXAMPLES



KEY


- - Dock Pipe
- ⊕ - Pipe Sleeve Bumper
- ⊥ - Cleat
- ⌋ - Multi-Purpose Bumper



FRAME ASSEMBLY

Items for STEP 1:

- (3) 2" x 6" x 117" boards
- (4) 2" x 6" x 48" boards
- (24) #8 x 2½" galvanized deck screws



On a flat surface, lay out three 2" x 6" x 117" boards 21¾" apart. Measure and mark boards at dimensions shown.

Attach four 2" x 6" x 48" boards as shown. Make sure the assembly remains square while securing with #8 x 2½" galvanized deck screws.

Items for **STEP 2:**


- | | |
|-----------------------------|--|
| (4) Outside Corner Brackets | (64) $\frac{3}{8}$ " x 3" Carriage Bolts |
| (4) Inside Corner Brackets | (64) $\frac{3}{8}$ " Flat Washers |
| (4) Corner Gussets | (64) $\frac{3}{8}$ " Lock Washers |
| (8) Joist Corner Brackets | (64) $\frac{3}{8}$ " Nuts |
| (16) Back Plates | |

Position Outside Corner Bracket centered top to bottom. Use the bracket as a drill guide and drill $\frac{3}{8}$ " holes completely through the boards.

Repeat for all the brackets.


**Refer to page 4 for layout of Hinges and Pipe Sleeves which need to be installed at this time.
See pages 5 & 6 for installation instructions.**

Attach brackets with $\frac{3}{8}$ " x 3" carriage bolts, $\frac{3}{8}$ " flat washers, $\frac{3}{8}$ " lock washers and $\frac{3}{8}$ " nuts as shown.



COMMERCIAL GRADE PIPE SLEEVE PS 1080 (Floating Only)

Attach the Pipe Sleeve to the Framing Kits as shown when assembling the corner hardware.



Refer to your specific project for locations.

ATTACHING HINGES



STRAIGHT CONNECTION

Attach the Hinges to the Frame Kits as you assemble the corner hardware.

Position a long Hinge (with notch) in each corner of one 4' side of the dock section as shown.

Position short Hinges (no notch) in each corner of one 4' side of the next dock section to be attached

Refer to your specific project for locations.



Note: The short Hinge (no notch) half should be attached to the end of dock sections furthest from shore.

90° CONNECTION

Attach the Hinges to the Frame Kits as you assemble the corner hardware.


Position a long Hinge (with notch) in corner of one 10' side of the dock section.

Position second long Hinge (with notch) so that the center distance between the mounting holes is 40⁷/₈" as shown.

Use the long Hinge (with notch) as a drill guide and drill ³/₈" holes completely through the board.

Use a Back Plate for reinforcement on both sides of the frame as shown.

Refer to your specific project for locations.




Items for STEP 3:

- (2) 2" x 6" x 117" boards
- (16) #8 x 2½" galvanized deck screws

Position 2" x 6" x 117" boards at dimensions shown.

Secure with #8 x 2½" galvanized deck screws as shown.




**Turn to page 13 if you are attaching a wood top.
Turn to page 14 if you are attaching the Resin Dock Top (PS 1320).**

ATTACHING FLOATS

Items for this STEP:



- (12) ¾" x 2" lag screws
- (12) ¾" flat washers

Position Floats as shown.



Use the Float as a drill guide and drill ¼" holes 2" deep on the sides only.

Secure with ¾" x 2" lag screws with ¾" washers as shown.




Do not attach a float to the gang-plank section closest to shore as shown.



The end without the float must rest firmly on land.

Refer to your specific project for locations.



COMMERCIAL GRADE AUGER PS 1100 (Floating Only)




Drill one ¾" hole in pipe 1½" up from the end. Insert Auger into the pipe, align holes and finish drilling opposite side. Secure with the nut and bolt provided.

READ ALL INSTRUCTIONS THOROUGHLY BEFORE YOU BEGIN CONSTRUCTION. STATIONARY OR ROLL-IN DOCK PROJECT STARTS HERE.

DOCK LAYOUT EXAMPLES




FRAME ASSEMBLY



Items for STEP 1:

- (3) 2" x 6" x 117" boards
- (4) 2" x 6" x 48" boards
- (24) #8 x 2½" galvanized deck screws



On a flat surface, lay out three 2" x 6" x 117" boards 21¾" apart. Measure and mark boards at dimensions shown.

Attach four 2" x 6" x 48" boards as shown. Make sure the assembly remains square while securing with #8 x 2½" galvanized deck screws.

Items for STEP 2:

- | | |
|-----------------------------|-------------------------------|
| (4) Outside Corner Brackets | (48) 3/8" x 3" Carriage Bolts |
| (4) Inside Corner Brackets | (48) 3/8" Flat Washers |
| (4) Corner Gussets | (48) 3/8" Lock Washers |
| (4) Joist Corner Brackets | (48) 3/8" Nuts |
| (8) Back Plates | |


Position Outside Corner Bracket centered top to bottom. Use the bracket as a drill guide and drill 3/8" holes completely through the boards.

Repeat for all the brackets.

Refer to page 8 for layout of Pipe Sleeves and Clips which need to be installed at this time.


See pages 9-11 for installation instructions

Attach Brackets and any Pipe Sleeves and Clips with 3/8" x 3" carriage bolts, 3/8" flat washers, 3/8" lock washers and 3/8" nuts as shown.




Note: *Install all hardware and check to make sure frame is square before tightening.*



ATTACHING PIPE SLEEVES



Attach the Pipe Sleeves to the frame as you assemble the corner hardware as shown. Secure with 3/8" x 3" carriage bolts, 3/8" flat washers, 3/8" lock washers and 3/8" nuts. (Figure 1)


Note: *If using 1 7/8" pipe, install (2) Back Plates PS 1017 behind each Pipe Sleeve in order to provide clearance necessary to adjust pipe inside sleeve. (Figure 2)*





NOTE:


*The Pipe Sleeves should be attached to the 10' side of the dock for a straight connection.
The Pipe Sleeves should be attached to the 4' side of the dock for a right-angle connection.*



ATTACHING CLIPS

STRAIGHT CONNECTION

Refer to your specific project for locations.



NOTE:

The end of the dock section with Pipe Sleeves will always have the clips with center tab pointing up.

Attach the Clips to the frame as you assemble the corner hardware.

Position a Clip with center tab pointing up in each corner of one 4' side of the dock section as shown.

Position Clips with center tab pointing down in each corner of one 4' side of the next dock section to be attached.


90° CONNECTION

Refer to your specific project for locations.

Attach the Clips to the frame as you assemble the corner hardware.

Position a Clip with center tab pointing up in corner of one 10' side of the dock section as shown.

Position second Clip with center tab pointing up so that the center distance between the outside mounting holes is $40\frac{7}{8}$ " as shown.



Using the Clip as a drill guide, mark the 4 holes and drill $\frac{3}{8}$ " holes completely through the board.


Attach with $\frac{3}{8}$ " x 3" carriage bolts, $\frac{3}{8}$ " flat washers, $\frac{3}{8}$ " lock washers and nuts.

Items for STEP 3:

- (2) 2" x 6" x 117" boards
- (16) #8 x 2½" galvanized deck screws

Position 2" x 6" x 117" boards at dimensions shown.

Secure with #8 x 2½" galvanized deck screws as shown.



**Turn to page 13 if you are attaching a Wood Top.
Turn to page 14 if you are attaching the Resin Dock Top (PS 1320).**

HOW TO ADJUST DOCK HEIGHT

Stationary



Roll-In




Figure 1




Figure 2



Position two $\frac{3}{8}$ " flange nuts into Pipe Sleeve as shown. (Figure 1)

Insert dock pipe into Pipe Sleeves at desired height.

Tighten pipe with $\frac{3}{8}$ " x 1" hex bolt and $\frac{3}{8}$ " flange nut as shown. (Figure 2)

ROLL-IN OPTION

Roll-In



Purchase Separately:


- (2) PS 1198 Dock Wheel Axle Kit
- (2) PS 1334 Dock Wheels
- (3) Dock Pipe ($1\frac{5}{8}$ " or $1\frac{7}{8}$ ")

Follow the complete assembly instructions included in your PS 1198 Dock Wheel Axle Kit.

SHOWN WITH
WOOD TOP

STATIONARY OPTION

Stationary




Purchase Separately:

- (2) PS 1023 Commercial Grade Foot Plate
- (2) Dock Pipe ($1\frac{5}{8}$ " or $1\frac{7}{8}$ ")


Attach foot plate to dock pipe as shown.

For Additional Support, the pipe can extend below the bottom of the foot plate. This allows the pipe to dig into the surface below.

SHOWN WITH
WOOD TOP



or




Note: Dock pipe longer than 8 feet may require additional cross bracing.

WOOD TOP ASSEMBLY

Stationary

Roll-In

Floating




Items for this step:

- (3) 5/4" x 6" x 48" boards
- (27) #8 x 2 1/2" galvanized deck screws

Position one board flush at each end of the frame and one directly in the middle as shown.

Secure each board with nine #8 x 2 1/2" galvanized deck screws.




SHOWN WITH
FLOATING FRAME

Items for this step:

- (18) 5/4" x 6" x 48" boards
- (162) #8 x 2 1/2" galvanized deck screws

Position boards equally spaced between existing boards.

Secure each board with nine #8 x 2 1/2" galvanized deck screws.




SHOWN WITH
FLOATING FRAME




**Turn to page 7 if you are building a Floating Dock.
Turn to page 12 if you are building a Roll In or Stationary Dock.**

RESIN DOCK TOP ASSEMBLY




Items for this step: (included in PS 1320 RESIN DOCK TOP)

- (4) dock top corners
- (6) dock top sides
- (16) $\frac{3}{8}$ " x $1\frac{1}{4}$ " hex bolts
- (32) $\frac{3}{8}$ " flat washers
- (16) $\frac{3}{8}$ " lock nuts



Assemble the tops into two halves as shown. Install $\frac{3}{8}$ " x $1\frac{1}{4}$ " hex bolts, $\frac{3}{8}$ " washers and $\frac{3}{8}$ " lock nuts at each starred location. **Finger tighten only.**





Note: If bolts are completely tightened, attaching the top to the frame will be difficult.

Items for this step:

(included in PS 1320 Resin Dock Top)

- (48) $\frac{1}{4}$ " x $1\frac{1}{2}$ " self-drilling hex screws
- (48) $\frac{1}{4}$ " fender washers



Position the two assembled halves together and center on the frame as shown.

Beginning with the exterior holes, secure with $\frac{1}{4}$ " x $1\frac{1}{2}$ " self drilling hex screws and fender washers. **Do not over tighten.**

Once Dock Top is secured to frame, completely tighten all hex bolts from previous step. Then slightly loosen these bolts/nuts ($\frac{1}{3}$ "- $\frac{1}{2}$ " of a turn) to allow for some expansion and contraction of Dock Top sections.

**SHOWN WITH
FLOATING FRAME**



**Turn to page 7 if you are building a Floating Dock.
Turn to page 12 if you are building a Roll In or Stationary Dock.**


ATTACHING ACCESSORIES

(PURCHASE SEPARATELY)

Stationary



Roll-In



Floating





MULTI-PURPOSE BUMPER PS 1352

(hardware not provided)

Position Bumper in desired location. Use Bumper as a drill guide and drill $\frac{1}{4}$ " holes 2" deep. Secure with $\frac{3}{8}$ " x 2" lag screws with $\frac{3}{8}$ " washers as shown.

Refer to your specific project for locations.



PLAYSTAR RESIN DOCK LADDER PS 1605

(HARDWARE PROVIDED)



Safe, easy way to climb onto your dock from the water.

Adjustable to 36" or 47" length.


Instructions packaged with ladder.

PIPE SLEEVE BUMPER PS 1188

(hardware provided)

Install two $\frac{3}{8}$ " nuts and $\frac{3}{8}$ " flat washers on each U-bolt as shown. Attach the Pipe Sleeve Bumper to the U-bolts around the Pipe Sleeve. Secure with $\frac{3}{8}$ " flat washers, $\frac{3}{8}$ " lock washers and $\frac{3}{8}$ " nuts.

Refer to your specific project for locations.




RESIN DOCK CLEAT 8" PS 1191

(Purchase hardware separately)

Position Cleat in desired position. Use Cleat as a drill guide and drill two $\frac{1}{8}$ " holes. Secure with $\frac{1}{4}$ " x 4" lag screws and $\frac{3}{8}$ " flat washers.

Refer to your specific project for locations.




PREMIUM DOCK CLEAT PS 1354

(Purchase hardware separately)

Position Cleat in desired location. Use Cleat as a drill guide and drill $\frac{1}{4}$ " holes 2" deep. Secure with $\frac{3}{8}$ " x 2" lag screws with $\frac{3}{8}$ " washers as shown.

Refer to your specific project for locations.





Thank You for choosing PortSide by PlayStar. Because it is our intention to make this a positive family experience, we have taken great care in preparing this product. Should you have any questions, or if we can assist you in any way, please call our friendly Customer Service Department for immediate action.

Do not return to the store.
Please call us Toll Free at 1-888-PLAYSTAR
(752-9782)

Monday through Friday, 8:00 A.M. to 5:00 P.M. C.S.T.

Ask for Customer Service.

We Will Gladly Help!

portsidedocks.com



PlayStar, Incorporated, Janesville, WI 53547

© 2018, 2010, PlayStar, Inc. Reproduction of this document in part or whole is prohibited without the permission of PlayStar, Inc.

Patents Pending or Protected by one or more of the following United States or Foreign Patents: US 6,098,564; US 6,145,463; US 7,153,064; CA 2,270,012; CA 2,261,438